

Analyzing the Effects of Surface Energy on Algae with Specialized Attachment Mechanisms



Marisa Rodriguez, Zahra Karimi, Dr. Virginia A. Davis,
Dr. David Blersch

Davis Research Group

Department of Chemical Engineering

SAMUEL GINN


COLLEGE OF ENGINEERING

The Importance of Algae

- Algae potentials: Wastewater treatment, catching runoff fertilizer, animal feed, nutritional supplements, biofuel, and more
- Algae has recently been popularized by media due to its potential as a biofuel and ExxonMobil's commercials on their algal research



<https://geneticliteracyproject.org/2018/01/15/new-generation-gmo-crops-dramatically-boost-biofuel-production/>



<https://www.mnn.com/earth-matters/animals/stories/20-things-you-didnt-know-about-cows>

The Importance of Algae

- One of the complications that come with algae are the inefficiency and cost of the harvesting process
- Most systems are designed for suspended growth of microalgae
- Research has been focused on microalgae rather than filamentous algae




Credit: Pacific Northwest National Laboratory

The Importance of Algae



- Filamentous algae preferable because they grow attached, can be mechanically harvested
- Much of filamentous algae's early stages of attachment are unknown
- Knowledge of attachment behavior can allow for manipulation of substrates to encourage or discourage growth

Micro Algae vs Filamentous (Macro) Algae

Micro algae attach to a surface that has been conditioned by bacteria and extracellular polymeric substance (EPS) and as the algae attach they form a biofilm on the surface



Limitations arise when the biofilm grows larger, it becomes difficult for algae near the growth material to receive light and nutrients



Grows more like a "normal plant" so the limitations that exist for microalgae do not apply

Current Work

Filamentous algae as found naturally in rivers and creeks:



- Previous research covered microalgae growth and attachment (*S. dimorphus*)
 - Developed protocol for microalgae culture growth, measurement, and attachment
- Filamentous algae respond best to flow environments
- Needed new protocol catered to filamentous macroalgae

Current Work- Cultivating

- Filamentous algae used: Oedogonium, Tribonema, and Stigeoclonium
- Pure algae strains from University of Texas
- Started growth in vial, fed Bold 3N Medium
- Kept under a growth lamp 24/7




Tribonema and Stigeoclonium cultures with bubbling



Oedogonium in a vial, very low concentration

Calculating Surface Energy

- The van Oss contact angle method was used to obtain surface energy parameter values to fit in the modified Young's Equation below
- Used 3 probe fluids: hexadecane, ethylene glycol, water



γ_{SG} = Solid-Gas
 γ_{SL} = Solid-Liquid
 γ_{GL} = Gas-Liquid

Modified Young's Equation


$$\cos\theta = -1 + \frac{2(\gamma_{sr}^{LW} \gamma_l^{LW})^{1/2}}{\gamma_l} + \frac{2(\gamma_{sr}^+ \gamma_l^-)^{1/2}}{\gamma_l} + \frac{2(\gamma_{sr}^- \gamma_l^+)^{1/2}}{\gamma_l}$$

This term accounts for Lifshitz van der Waals forces

These two terms account for acid-base pair/ polar interactions

Calculating Surface Energy


Probe Fluid	Average Contact Angle
Water	73.0°
Ethylene glycol	48.9°
Hexadecane	17.2°



Surface Energy Parameters (mJ/m ²)		
γ^{LW}	γ^{-}	γ^{+}
26.3	11.5	1.3

Filamentous Algal Attachment Tests

- Substrates tested: glass, polylactic acid (PLA) disks
- PLA disks made via tortilla press
- Substrates were placed in glass containers filled with 20 mL ultra-pure water and 10 mL of undiluted algae, then left undisturbed for 24 and 48 hrs
- Distortion of the images occurred due to water film



Filamentous Algal Attachment Tests




This “star” formation is the specialized attachment mechanism for Stigeoclonium


Filamentous Algal Attachment Tests

Stigeoclonium on Glass



48 hrs



Stigeoclonium on PLA



Filamentous Algal Attachment Tests





Oedogonium specialized attachment mechanisms are holdfasts, small “hand”

Filamentous Algal Attachment Tests

Oedogonium on Glass

48 hrs

Oedogonium on PLA



Conclusions

- Filamentous macroalgae are more difficult to grow in a lab environment, a protocol for keeping a culture was made
- Successful attachment with *Stigeoclonium* to both glass and PLA
- No successful attachment yet with *Oedogonium*, likely due to filamentous strand length

Future Work

- Additional substrates, such as Teflon, for attachment tests
- Attachment tests varying light exposure
- Cutting Oedogonium filaments to see the affect on attachment

Acknowledgements

- The Virginia Davis Research Group
- The Undergraduate Research Fellowship Program of Auburn University



Questions?


Calculating Surface Energy

Modified Young's Equation

$$\cos\theta = -1 + \frac{2(\gamma_{sr}^{LW} \gamma_l^{LW})^{1/2}}{\gamma_l} + \frac{2(\gamma_{sr}^+ \gamma_l^-)^{1/2}}{\gamma_l} + \frac{2(\gamma_{sr}^- \gamma_l^+)^{1/2}}{\gamma_l}$$

- Accounts for Lifshitz van der Waals forces
- VdW: dipole-dipole (polar), dispersion (nonpolar), and hydrogen bonding
- Lifshitz: no pairwise additivity, looks at bulk whole bodies

- Accounts for acid-base/polar interactions
- Attraction or repulsion based on polarity





$$G^{TOT}(d) = G^{AB}(d) + G^{LW}(d) + G^{EL}(d)$$

G^{AB} Acid-base Interactions

G^{LW} Lifshitz-van der Waals Interactions

G^{EL} Electrostatic Interactions

Calculating Surface Energy




γ_{SG} = Solid-Gas
 γ_{SL} = Solid-Liquid
 γ_{GL} = Gas-Liquid


Three Liquids used:
Acid/base value of zero: Hexadecane
Polar: Water
Nonpolar: Ethylene Glycol

Calculating Surface Energy


Water



Ethylene Glycol



Calculating Surface Energy



Bold 3N Medium

#	Component	Amount	Stock Solution Concentration	Final Concentration
1	NaNO ₃ (Fisher BP360-500)	30 mL/L	10 g/400mL dH ₂ O	8.82 mM
2	CaCl ₂ •2H ₂ O (Sigma C-3881)	10 mL/L	1 g/400mL dH ₂ O	0.17 mM
3	MgSO ₄ •7H ₂ O (Sigma 230391)	10 mL/L	3 g/400mL dH ₂ O	0.3 mM
4	K ₂ HPO ₄ (Sigma P 3786)	10 mL/L	3 g/400mL dH ₂ O	0.43 mM
5	KH ₂ PO ₄ (Sigma P 0662)	10 mL/L	7 g/400mL dH ₂ O	1.29 mM
6	NaCl (Fisher S271-500)	10 mL/L	1 g/400mL dH ₂ O	0.43 mM
7	P-IV Metal Solution	6 mL/L		
9	Soilwater: GR+ Medium	40 mL/L		
10	Vitamin B₁₂ Solution	1 mL/L		